

Rekluse Motor Sports z-Start Pro Tuning Chart KTM 65

198-139

Manual Revision: 100907

z-Start Pro

Engagement RPM	Engagement Rate	2 Inch (Shortest) Black Spring (C200-L1)	2 Inch Black Spring (C200-L2)	2 Inch (Tallest) Spring (C200-L3)	# of Steel Balls	# of TC Balls
Low	Harder	X			25	5
Medium*	Harder		X*		25	5
High	Harder			X	25	5
Low	Softer	X			30	0
Medium*	Softer		X*		30	0
High	Softer			X	30	0

*** Recommend initial settings**

Note: TC balls must be evenly spaced around the pressure plate.

The pattern for the 5 TC ball setup is **1 TC ball followed by 5 steel balls**.

To distinguish between steel balls and the heavier TC balls use a low powered magnet (magnetic screwdriver works well). With a low powered magnet, the TC balls do not seem magnetic.