

Rekluse Motor Sports z-Start Pro Tuning Chart Polaris Outlaw – 450/525 KTM 450/525 XC ATV

198-850

Manual Revision: 092107

z-Start Pro

Engagement RPM	Engagement Rate	2 Inch Taller Black Spring (C200-L7)	2 Inch Red Spring (C200-M3)	2 Inch Taller Red Spring (C200-M4)	# of Steel Balls	# of TC Balls
Low	Harder	X			15	12
Medium*	Harder		X		15	12
High	Harder			X	15	12
Low	Softer	X			18	9
Medium*	Softer		X		18	9
High	Softer			X	18	9

*** Recommend initial setting**

Note: TC balls must be evenly spaced around the pressure plate.

The pattern for the 12 TC ball setup is **4 TC balls followed by 5 steel balls.**

The pattern for the 9 TC ball setup is **3 TC ball followed by 7 steel balls.**

To distinguish between steel balls and the heavier TC balls use a low powered magnet (magnetic screwdriver works well). With a low powered magnet, the TC balls do not seem magnetic.

